

V100CFCONTUBE

Condensation drain for VEX100CF



Reference arguments

Condensation can occur in the VEX exhaust area if there is high humidity in the extract air, and the air is passing at high speed through the heat exchanger.

In such cases it is recommended to use a VEX unit with a Contube kit to lead the condensate to the VEX base tray.

In the case of VEX 100CF Vertical we also recommend mounting a heating cable SIPHONHE02 round the hose from the above-mentioned drain in order to avoid freezing when condensate passes through the cold parts of the VEX.